



ASSEMBLY GUIDE: G2 FRONT PANNIER ROD KIT

Version 1.0



Installation of the G2 Front Pannier Rod Kit



CONTENTS

Overview	1
Parts List	1
Tool List	1
1. Pannier Rod Holder Installation.....	2
2. Pannier Rod Installation	5




OVERVIEW

This assembly guide details installation of the G2 Front Pannier Rod Kit. If you have any questions, or require any further assistance, please contact techsupport@gocycle.com.

PARTS LIST

To successfully complete the procedure you will require the following parts:



	Part Code	Part Description	Quantity
A	2406	M6x65 SS full thread	1
BA, BC	2386	G2 pannier rod holder parts A and C	1
C	2389	Pannier rod type 250mm	1
D	2390	End fitting	1

NOTE: Pannier briefcase sold separately. See www.gocycle.com for details.


TOOL LIST

To successfully complete the installation of the G2 Front Pannier Rod Kit, you will require the following tools. *You can purchase special KKL tools by their tool number detailed below.*

Part Code	Tool Description
	4mm Allen key
	5mm Allen key
	T30



1. PANNIER ROD HOLDER INSTALLATION



1.1. Depending on the frame number, Use a 4mm Allen key or a Torx T30 to undo the handlebar stem bolt, as shown.

1.2. Remove the bolt completely from the handlebar stem.

Note: Take care to keep the handlebar in the same position. Do not twist the handlebars, as doing so may cause damage and loss of function.

Note the differences between Part A (BA) and Part C (BC).

Part C (BC) has a larger hole (indicated).



1.3. Insert the M6 bolt (A) into the smaller hole in Part A of the pannier rod holder (BA). Insert the M6 bolt into the Handlebar Stem.



1.4. Thread the M6 Bolt (A) into the handlebar stem.



1.5. Tighten the bolt (A) using a 5mm Allen key until Part A (BA) is flush against the handlebar stem.



1.6. Locate the threaded hole in Part C (BC) of the pannier rod holder.

1.7. Slide Part C (BC) onto the end of the M6 bolt (A) so it is flush against the Handlebar Stem.

1.8. Thread M6 captive nut (E) onto the M6 bolt (A) but do not tighten fully.



2. PANNIER ROD INSTALLATION



2.1 Unscrew the bolt by one complete revolution so both parts, BA and BC, are free to spin.



2.2 Now install the pannier rod (C) through parts BA and BC as shown.



2.3 Adjust the position of the pannier rod (C) so it is located centrally.



2.4 Use the 5mm Allen key to tighten the bolt (A).



2.5 Use a 5mm Allen Key to tighten the M6 captive nut (E).

Note: The final position of the pannier rod should be as shown, in a downward position and touching the handlebar stem.



Incorrect position! The pannier rod is upwards and is not touching the handlebar stem.



2.6 Install both rod ends (D).

2.7 Installation of the G2 Pannier Rod Kit is complete.

A compatible pannier bag can now be fitted. See www.gocycle.com for more details.

Note: G2 Pannier Briefcase sold separately.

IMPORTANT NOTE: THE ABOVE ASSEMBLY STEPS MUST BE CARRIED OUT IN ORDER. FAILING TO DO SO MAY RESULT IN DAMAGE TO THE GOCYCLE.

If you have any further queries or comments, please contact Gocycle Technical Support:

techsupport@gocycle.com